

HQ.#	OEM.#	Description
HYBT01	A4J16002 A2	Push Button,24V
HYBT02	AK32	Push Button,Installation Hole Size:34
HYBT03	AK-4B	Push Button,Installation Hole Size:33






HQ.#	OEM.#	Description
HYWR01		Door Roller, $\Phi 66 \times 15 \times 6202$
HYWR02		Door Roller, $\Phi 45 \times 15 \times \Phi 12$
HYWR03		Door Roller, $\Phi 84 \times \Phi 77 \times 17 \times M10$
HYWR04		Door Roller, $\Phi 30(6200) \times 33 \times M6$
HYWR05		Door Roller, $\Phi 70 \times 10 \times 6001$


HQ.#	OEM.#	Description
HYGS02		Guide Shoe Insert, $120 \times 22 \times 6$ Guide Shoe Insert, $80 \times 50 \times 57 \times 7$

HQ.#	OEM.#	Description
HYDS01		Door Slider, $96 \times 42 \times 11$

HQ.#	OEM.#	Description
HYLO01	GLKS-M34	Door Lock
HYLO02		Triangle Lock
HYLO03		Triangle Lock
HYLO04		Door Lock
HYLO05		Door Lock

HQ.#	OEM.#	Description
HYSS01	ID2-F8-AS1/AS2	Limited Switch
HYSS02	BUP-50-HD	Limited Switch
HYSS03	BUP-50-H(BUD-50-H)	Limited Switch
HYSS04	PF125/PFI25-8DN	Proximity Switch
HYSS05	HLC-2004 STVF5	Load Sensors





HQ.#	OEM.#	Description
HYTT01	HHT-WB100	Service Tool,STVF 9

HQ.#	OEM.#	Description
HYDI01	HIPD-CAN	Display Board,STVF5/STVF7
HYDI02	HIP-CMO	Display Board,STVF5/STVF7
HYDI03	OPB-CAN-INDICATOR	Display Board,STVF5/STVF7
HYDI04	HIPD-CAN-LCD	Display Board,STVF5/STVF7
HYDI05	HPID-CAN	Display Board,STVF5/STVF8
HYDI06	HPID-CANV3.1	Display Board
HYDI07	HPID-CANV3.2	Display Board
HYDI08	COLTD12SEG	Display Board

HQ.#	OEM.#	Description
HYPCB01	HIDC-N	PC Board
HYPCB02	MPCU	PC Board,BOARD 204C1699 H22
HYPCB03	OPB-340	PC Board
HYPCB04	PWR	PC Board
HYPCB05	TCB-3	PC Board
HYPCB06	M33 BD REV .D1	PC Board
HYPCB07	MCU	PC Board,STVF7,DWG N 20400065
HYPCB08	TNP7A	PC Board,STVF7
HYPCB09	OPB-340	PC Board,STVF5/STVF7
HYPCB10	CCB-7	PC Board,STVF5/STVF7
HYPCB11	HIVD900SS	PC Board,STVF5/STVF8
HYPCB12	PSDM	PC Board
HYPCB13	H9G 15SF R4.0 CAUTION	PC Board
HYPCB14	TPB-2	PC Board
HYPCB15	XDDY-12V V3.3	PC Board

